



**AUXILIARY MODULE CALIBRATIONS AVAILABLE FOR STEINLITE SB900  
LISTED ALPHABETICALLY WITHIN COMMODITY SECTIONS  
AS OF 01/22/09**

Main Commodity	ID Number	Product	Testing Wt. In Grams	Moisture Range in Percent	Temperature Limits in Degrees F
<b>ALFALFA</b>	190	Alfalfa	250	8-18	60-95
	122	Alfalfa Pellets #3	250	5-12.5	60-95
	123	Alfalfa Meal (Ground Pellets)	200	6-13	60-95
<b>BARLEY</b>	222	Barley 85	250	9-18	50-95
	397	Hulled Barley	250	8-18	65-95
	142	Barley Malt	220	5-15	50-95
	711	Barley Meal (flour)	200*	2-10	60-95
	702	Brocked Barley (meal)	250	10-19	60-95
	193	Steam Rolled Barley	175	10-16	60-95
	271	Steam Rolled Barley #2	165	10-16	60-95
<b>BEANS</b>	374	Adzuki Beans	250	10-19	60-95
	705	Bayo Bean	250	8-16	60-95
	126	Black Beans	250	11-18	60-95
	361	Black Beans #2 (TC)	250	10-30	35-100
	706	Broad Bean	250	6-14	60-95
	713	Broad Bean Meal (flour)	200*	7-15	60-95
	697	Canario Bean	250	10-18	60-95
	127	Cocoa Beans	225	4-10	60-90
	362	Cranberry Beans (Bush) (TC)	250	10-30	35-100
		Cranberry Beans	250	9-19	60-95
	363	Cranberry Beans (Vine) (TC)	250	10-30	35-100
	128	Erimo Shozu Beans	250	9-20	60-90
	129	Garbonzo Beans	250	9-19	60-100
	131	Hime Tebo Beans	250	9-20	60-90
	133	Kidney Beans (Dark Red)	250	9-20	60-95
	365	Kidney Beans #2 (Dark Red) (TC)	250	10-30	35-100
	132	Kidney Beans (Light Red)	250	9-18	60-95
	227	Kidney Beans #2 (Light Red)	250	9-18	60-95
	366	Kidney Beans #3 (Light Red) (TC)	250	10-30	35-100

**AUXILIARY MODULE CALIBRATIONS AVAILABLE FOR STEINLITE SB900  
LISTED ALPHABETICALLY WITHIN COMMODITY SECTIONS**

Main Commodity	ID Number	Product	Testing Wt. In Grams	Moisture Range in Percent	Temperature Limits in Degrees F
<b>BEANS CONT'D</b>	437	Lima Beans (Baby)	250	6-30	60-95
	438	Lima Beans (Green Baby)	250	6-30	60-95
	439	Lima Beans (Large)	250	7-22	60-95
	441	Lima Beans (Speckled)	250	7-30	60-95
	134	Lupin Beans	250	9-18	50-90
	135	Mung Beans (Giant)	250	9.5-15	60-95
	367	Navy Beans (TC)	250	10-30	35-100
	136	Navy Pea Beans #2	250	11-20	60-95
	130	Great Northern Beans #2	250	9-18	50-95
	364	Great Northern Beans #3 (TC)	250	10-30	35-100
	696	Panamito Bean	250	10-18	60-95
	137	Pink Beans	250	9-20	60-90
	138	Pinto Beans #3	250	9-18	65-95
	368	Pinto Beans #4 (TC)	250	10-30	35-100
	440	Pinto Beans (Split)	250	7-30	60-95
	443	Red Beans (Small)	250	7-30	60-95
	703	Strawberry Bean	250	9-19	60-95
369	White Beans (Small) (TC)	250	10-30	35-100	
442	Yellow-Eye Pea Beans	250	5-27	60-95	
<b>BEEET</b>	395	Raw Sugarbeet (TC)	110	6-25	50-100
	358	Processed Sugarbeet (TC)	200	5-30	50-100
	396	Treated Sugarbeet (TC)	200	8-18	50-100
	391	Sugarbeet Pulp w/Molasses	110**	4-13.5	50-90
	176	Sugarbeet Pulp Pellets	250	6-15	50-90
		Sugarbeet Pulp Pellets w/Molasses	250	6-15	50-90
<b>BIRD SEED MIX</b>	467	Exclusively for the Birds	250	6-15	60-95
	466	Squirrel Free	250	6-15	60-95
	700	Birdseed	250	6-14	60-95
<b>BLOOD</b>	198	Blood Meal	225	8-12	65-95
	245	Blood Meal #2	225	8-17	65-95
<b>BONE</b>	172	Gel Bone #2	300	4-10	65-90
	197	Gel Bone #4	300	3-11	65-90
	199	LoProtein Meat & Bone Meal#2 (grd)	250	5-10	65-90
	203	HiProtein Meat & Bone Meal#2 (grd)	225	5-11	60-90
<b>BUCKWHEAT</b>	382	Buckwheat #2	250	8-30	60-95
	426	Buckwheat Groats	250	6-14.5	50-95
<b>CANOLA</b>	432	Spring Canola	250	5.5-12.5	70-90
	514	Rapeseed Meal	200	8-14	60-100

**AUXILIARY MODULE CALIBRATIONS AVAILABLE FOR STEINLITE SB900  
LISTED ALPHABETICALLY WITHIN COMMODITY SECTIONS**

Main Commodity	ID Number	Product	Testing Wt. In Grams	Moisture Range in Percent	Temperature Limits in Degrees F
<b>CEREAL (PUFFED)</b>	468	Corn	25**	3-12	60-95
	471	Kamut	28**	3-12	60-95
	472	Kashi	40**	3-12	60-95
	470	Rice (Brown)	28**	3.5-12	60-95
	469	Wheat	25**	3-12	60-95
	701	Quinoa (gluten free)	275	10-21	60-95
<b>CITRUS</b>	431	Citrus Pulp (TC)	125	6-29.5	35-110
	150	Citrus Pulp Pellets	250	5-15	60-110
	151	Citrus Pulp Pellets (Ground)	250	5-15	60-110
	174	Citrus Pulp Pellets (Screened)	250	5-15	60-110
<b>COFFEE</b>	154	Green Coffee Beans	250	12-22	60-95
	156	Decaffeinated Green Coffee Beans	250	8-14	60-90
	155	High Moisture Green Coffee Beans	250	25-40	60-100
	152	Superior Green Coffee Beans	250	9.5-16	60-95
	157	Decaffeinated Coffee Beans	250	8-13	60-90
	153	Oro Coffee Beans	250	10-16	65-95
	158	Parchment Coffee Beans	175	10-20	60-95
	160	Parchment Coffee Beans #2	175	13-21.5	60-95
	616	Parchment Pergamino Coffee Beans #3	175	8-50	60-100
	159	Pergamino Coffee Beans	175	9-20	60-95
	537	Pergamino Coffee Beans (Hi-Moist)	300	21-50	60-95
	148	Roasted Coffee Beans	140	2-6	60-100
	161	Semi-Roasted Coffee Beans	250	5-10	60-95
	149	Ground Roasted Coffee Beans	140	2-6	60-100
	651	Hawaii Parchment	175	8-30	60-95
652	Hawaii Less Parchment	250	4-22	60-95	
<b>CORN</b>	139	Corn	250	10-36	50-90
	147	Corn #3	250	10-36	50-90
	237	Corn #4 (TC)	250	10-35	35-110
	291	Corn #6 (with test/weight)	250	10-35	50-90
	385	Corn #6 (without test/weight)	250	10-35	40-100
	473	Corn #7 (TC) Standard	250	10-35	35-110
	427	Crimped Roasted Corn	250	8-18	70-110
	398	Flaked Corn	200	14-30	40-100
	208	Flaked Corn #2	165	15-30	60-95
	214	Grain Roasted Flaked Corn (TC)	210	4-15	70-120
	425	Steam Rolled Flaked Corn	125	10-25	60-95
	527	Corn – Toasted	175	1-9	60-95
	180	Corn Grits	250	10-16	50-90

**AUXILIARY MODULE CALIBRATIONS AVAILABLE FOR STEINLITE SB900  
LISTED ALPHABETICALLY WITHIN COMMODITY SECTIONS**

Main Commodity	ID Number	Product	Testing Wt. In Grams	Moisture Range in Percent	Temperature Limits in Degrees F
<b>CORN CON'T</b>	166	Corn Grits #2	250	10-20	50-90
	181	Corn Grits #3	250	10-18	50-90
	287	Flaking Grits (TC)	250	11-19	60-120
	422	Ground Corn	250	10-20	50-95
	661	Ground Flaked Corn	250	4-22	60-95
	400	High Moisture Ground Corn	250	21-31	40-100
	399	Hi-Moist Reconstituted Ground Corn	250	20-30	40-100
	255	Ground Corn Cobs	100	8.5-17	60-95
	289	Corn Hominy Feed #3	200	8-20	70-100
	182	Corn Meal #3	250	10-20	50-95
	288	Corn Meal #4 (TC)	250	10-15	60-120
	584	Corn Meal #5 (Frito Lay) (TC)	250	8-20	35-120
	619	Corn Meal #6 (Frito Lay) (TC)	250	8-26	35-120
	572	Corn Meal Mix	250	11-19	60-95
	371	Rolled Corn #2	250	12-20	65-90
	302	Corn Screenings #2	250	9-20	50-90
	270	Steam Rolled Corn #2	175	10-18	50-100
	655	Mexican White Corn	250	6-38	60-95
	712	Roasted Yellow Corn Meal (flour)	200*	9-18	60-95
	704	Soft White Mote Corn	250	10-18	60-95
709	White Corn Meal (flour)	200*	10-18	60-95	
698	White Flint Corn	250	10-18	60-95	
695	X-Large Yellow Kernel Corn	250	10-18	60-95	
708	Yellow Dent Corn Meal (flour)	200*	9-17	60-95	
<b>COTTONSEED</b>					
	125	Undelinted Cottonseed #2	150**	6-22	60-95
	561	Undelinted Cottonseed #3	150**	5-24	60-95
	613	Undelinted Cottonseed #4	150**	5-25	50-115
	562	Undelinted Roller Milled Cottonseed	150**	4.5-23	60-95
	563	Undelinted Cottonseed Cake	200**	4-13	60-95
	143	Mechanically Delinted Cottonseed #2	200**	6-23	60-90
	218	Acid Delinted Cottonseed	250	7-17.5	60-90
	614	Acid Delinted Cottonseed #2	250	6-18	50-115
	517	Cottonseed Raw Ground Meats	225	7-13	60-95
	518	Cottonseed Flakes (TC)	200	6-14	60-115
	354	Cooked Cottonseed	250	8-16	65-90
	305	Cooked Cottonseed #2 (TC)	250	5-13	70-120
	306	Expanded Cottonseed (grd&scrnd)(TC)	225	5-13	70-120
	355	Cottonseed Meal #2 (ground)	250	9-17	50-90
	356	Cottonseed Meal #2 (unground)	250	9-17	50-90
	307	Cottonseed Meal #3 (ground)	225	9-17	60-100
<b>CRAMBE</b>	333	Crambe	150	6-18	50-90

**AUXILIARY MODULE CALIBRATIONS AVAILABLE FOR STEINLITE SB900  
LISTED ALPHABETICALLY WITHIN COMMODITY SECTIONS**

Main Commodity	ID Number	Product	Testing Wt. In Grams	Moisture Range in Percent	Temperature Limits in Degrees F
<b>DISTILLERS</b>					
<b>DRIED GRAINS</b>					
	141	Distillers Dried Grains	230	6-17	50-95
	266	Distillers Dried Grains (TC)	150	5-15	50-120
	300	DDG w/solubles #2 (Mingler)(TC)	150	20-30	70-120
	299	DDG w/solubles #2 (Rotary)(TC)	150	6-17	70-120
<b>FEED</b>	607	Dog Food	210	5-25	35-120
	482	Feed Meal (Cattle)	175	8-20	50-90
	483	Feed Pellets (Cattle)	250	8-20	50-90
	394	Pork Feed	250	10-19	55-95
	484	Pork Finisher Feed	250	10-20	55-90
	523	Feathermeal-Rendered Animal Protein (R.A.P.)	250	4-12	60-95
	487	Feed Meal #2 (Poultry & Swine)	250	10-16	70-120
	304	Feed Pellets #2 (Poultry & Swine)	250	10-20	55-95
	566	Feed Pellets – Urea #850	225	8-16	60-95
Feed Con't	567	Feed Pellets – 10's #851	225	8-18	60-95
	568	Feed Pellets – 33's #852	250	8-16	60-95
	569	Feed Pellets – Fiber	225	8-16	60-95
	570	Feed Pellets – Buffer	250	8-16	60-95
	571	Feed Pellets – Vitamin	250	8-16	60-95
	687	Feed Pellets – Cargil	250	8-17	60-95
<b>FISH</b>	246	Fish Meal #2	250	7-17	55-100
<b>FLOWER SEEDS</b>	488	Alyssum – Lavender	130	4-12	60-95
	502	Aster – Pot “N” Patio – Scarlet	200	4-12	60-95
	547	Balsam	200	4-12	60-95
	505	Basil – Herb – Green Bouquet	190	4-12	60-95
	509	Caspia – Statice	300	4-12	60-95
	546	Cosmos	150	4-12	60-95
	489	Dahlia – Figaro Improved	90	4-12	60-95
	503	Daisy – Dahlberg – Golden Fleece	150	4-12	60-95
	490	Delphinium – Dwarf White Shade	115	4-12	60-95
	499	Gazania – Daybreak Pink	150	4-12	60-95
	491	Geranium w/hull – Scarlet Border	115	4-12	60-95
	500	Geranium (no hull) – Scarlet Border	250	4-12	60-95
	504	Gerbera – California Mix	125	4-12	60-95
	507	Lantana – Yellow	200	4-12	60-95
	506	Lavender – Herb – Lavender Lady	200	4-12	60-95
	508	Lobelia – Cambridge Blue	200	4-12	60-95
	501	Marigold-Marvel Yellow-Coated Hi-Germ	130	4-12	60-95
	492	Marigold-Marvel Yellow (no tail)	115	4-12	60-95

**AUXILIARY MODULE CALIBRATIONS AVAILABLE FOR STEINLITE SB900  
LISTED ALPHABETICALLY WITHIN COMMODITY SECTIONS**

Main Commodity	ID Number	Product	Testing Wt. In Grams	Moisture Range in Percent	Temperature Limits in Degrees F
	493	Marigold-Marvel Yellow w/tail	45**	4-12	60-95
	548	Moonflower	250	4.6-12	60-95
	513	Nicotiana – Mixed	150	4-12	60-95
	511	Petunia-Single Grand-White Dreams	150	4-12	60-95
	512	Snapdragon – Mixed	125	4-12	60-95
	494	Sweet Pea – Royal Mix	250	4-12	60-95
	498	Verbena – Burgundy IVE55	150	4-12	60-95
	495	Vinca – Pretty In White	200	4-12	60-95
	496	Viola – Princess Blue	200	4-12	60-95
	510	Zinnia – Lollipop Mix	120	4-12	60-95
	497	Zinnia – Star Orange	100	4-12	60-95
<b>FRUIT</b>	474	Apples	110**	15-30	60-95
<b>(Dehydrated/ &amp; Meal)</b>	624	Apple Meal	250	1-9	40-110
	621	½,1/4, 3/8 Granny Smith Apples	88**	1-29	40-110
	622	Mixed Apple Pie	110**	11-29	40-110
	623	¼ Mixed Apples	110**	1-29	10-110
	459	Apricots Large Whole	250**	16-30	60-95
	460	Apricots Pieces	250**	16-33	60-95
	710	Banana Meal (flour)	200*	6-14	60-95
	620	Black Sweet Cherries Dhy	285*	8-26	35-120
	456	Blueberries Small	200*	10-25	60-95
	457	Blueberries Large	160*	10-25	60-95
	520	Cherries	285*	11.2-18	60-95
	476	Cranberries	250**	7-21	60-95
	463	Dates Pieces	200*	11-17	60-95
	464	Papaya Pieces	250*	5-18	60-95
	465	Pineapple Pieces	200*	6-17	60-95
	461	Prunes Whole	275**	18-37	60-95
	462	Raisins Large Whole	200*	9-18	60-95
	519	Strawberries	220*	10.9-14	60-95
	477	Tomatoes (high moisture)	125**`	14-33	60-95
	475	Tomatoes (low moisture)	70**	6-13	60-95
<b>GRAIN SCREENING</b>	393	Aspirated Grain Screenings	165**	10-15.5	60-90
	410	Aspirated Grain Screening Pellets	250	9-17	60-90
<b>GRASSES AND FORAGE SEEDS</b>	412	Bahia	250 ##	9.5-17.5	70-90
	413	Bermuda (Unhulled)	200 ##	10-18	65-90
	414	Bermuda (Hulled)	300 ##	9-19	65-95
	605	Big Bluestem Andropogen Geradi	70 ##**	7-35	40-115
	415	Canary	250 ##	9-18	65-95
	609	Centipede	250	9-27	35-120

**AUXILIARY MODULE CALIBRATIONS AVAILABLE FOR STEINLITE SB900  
LISTED ALPHABETICALLY WITHIN COMMODITY SECTIONS**

Main Commodity	ID Number	Product	Testing Wt. In Grams	Moisture Range in Percent	Temperature Limits in Degrees F
	377	Clover (Alsike)	300 ##	7-19.5	65-95
	416	Clover (Crimson)	300 ##	9-18	65-90
	347	Clover (Red)	300 ##	7-19.5	65-95
	612	Eastern Gama Grass	250	7-37	35-120
	115	Fescue #3 (K-31)	125 ##	9.5-30	60-90
	559	Fescue #4 (K-31)	125 ##	6-33	60-95
	452	Fescue (Chewings)	80 ##**	6-50	60-95
	417	Fescue (Creeping Red)	125 ##	10-18	60-95
	453	Fescue #2 (Creeping Red)	80 ##**	6-46	60-95
	454	Fescue (Hard)	80 ##**	6-50	60-95
	455	Fescue (Tall Turf)	90 ##	6-50	60-95
	313	Lespedeza #2 (Unhulled Kobe)	150 ##	8-20	60-90
	293	Lespedeza (Unhulled Korean)	250 ##	9-18	70-90
	295	Lespedeza (Unhulled Sericea)	150 ##	10-18	60-95
	348	Lespedeza (Hulled Sericea)	275 ##	10-18	60-95
	608	Little Bluestem	40 ##**	7-35	35-120
	444	Rye (Annual)	100 ##	6-50	60-95
	451	Rye (Perennial)	90 ##	6-50	60-95
	606	Sideoats Grama	60 ##**	7-35	40-115
GRASS & FORGAGE CON'T	185	Sudan	250 ##	5-30	60-95
	598	Switch Grass	260	7-32	35-120
	378	Timothy	250 ##	8.5-18	60-95
	383	Trefoil	250 ##	8-20	60-95
	418	Vetch (White Cahaba)	250 ##	10-18	60-95
	419	Vetch (Hairy)	250 ##	10-23	60-90
	611	Yellow Indian Grass	90 ##**	7-35	35-120
<b>INDUSTRIAL PRODUCTS</b>					
	633	Renfil #80 Organic Fiber	150	0-10	60-95
	634	Renfil #30 Organic Fiber	150	0-10	60-95
	635	Renfil #16 Organic Fiber	150	0-10	60-95
LINSEED	316	Linseed Meal #2	225	10-15	60-95
MARIGOLD	600	EMFM (Extracted Marigold)	175	12-20	60-90
MILLET	381	Japanese Millet	200	8-20	60-95
	184	Pearl Millet #2	250	5-30	65-95
	183	Proso Millet Red & White	250	9.5-18	65-95
	257	Proso Millet #2	250	10-19	65-95
MILO	370	Milo	250	9-22	50-95

**AUXILIARY MODULE CALIBRATIONS AVAILABLE FOR STEINLITE SB900  
LISTED ALPHABETICALLY WITHIN COMMODITY SECTIONS**

Main Commodity	ID Number	Product	Testing Wt. In Grams	Moisture Range in Percent	Temperature Limits in Degrees F
	213	Milo #6 (TC)	250	5-30	35-110
	352	Rolled Milo	175	10-21	60-90
	445	Steam Rolled Milo	200	9-19	50-100
	196	Flaked Milo	165	15-30	50-90
	216	Grain Roasted Flaked Milo (TC)	165	4-15	70-120
	615	Roasted Flaked Milo #2	61**	4-18	35-120
<b>MOLASSES</b>	694	Dried Molasses	225	1-9	60-95
<b>MUSTARD</b>	411	Yellow Mustard	250	7-17	65-95
<b>NUTS</b>	283	Almonds (unshelled)	165	3-16	60-100
	285	Almonds (shelled & blanched)	200	2-15	40-110
	580	Almonds (diced & blanched)	210*	1-13	35-110
	579	Almonds (meal blanched)	200*	1-13	35-110
	581	Almonds (sliced & blanched)	170*	1-13	35-110
	582	Almonds (slivered & blanched)	200*	1-13	35-110
	583	Almonds (whole & blanched) #2	200*	1-13	35-110
	630	Almonds (dry roasted diced) (TC)	210	1-4	40-110
	656	Almonds (meal Natural w/skin)	200	3-6	60-95
<b>NUTS CON'T</b>	657	Almonds (Sliced Natural w/skin)	175*	3-7	60-95
	658	Almonds (Diced Natural w/skin)	225	3-7.5	60-95
	686	Almonds (blanch Lo Moisture whole)	200	1-9	60-95
	729	Almonds (shelled) Revised	200	2-15	50-100
	296	Brazil (shelled whole)	200*	2-14	60-95
	273	Cashews (unshelled) (TC)***	200*	5-19	50-100
	274	Cashews (shelled whole) (TC)	200*	2-13	50-100
	275	Cashews (shelled pieces) (TC)	200*	2-13	50-100
	663	Hazelnuts Casina (w/shell) small	160*	3-17	50-100
	664	Hazelnut Jumbo Giant Ennis	200*	3-17	60-95
	665	Hazelnut Field Run Ennis	200*	3-17	60-95
	677	Hazelnut Ground Meats & shells	225	5-17	60-95
	260	Hazelnuts (unshelled) (TC) Orchard Sm	200*	3-16	50-100
	261	Hazelnuts (unshelled) Jumbo (TC)	200*	3-16	50-100
	565	Hazelnuts (unshelled) X-Lrg. Barcelona	150*	2-15.5	60-95
	262	Hazelnuts (shelled) Jumbo (TC)	200*	3-16	50-100
	564	Hazelnuts (kernels X-Lrg. Barcelona)	175*	2-12	60-95
	331	Hazelnuts #2 (shelled) Orchard Sml (TC)	200*	3-15	50-100
	297	Macadamia (shelled pieces)	150*	2-14	60-95
	597	Macadamia (whole shelled)	250*	1.5-15	60-100
	200	Peanuts – Shelled Runner	250	6-19	65-95
	201	Peanuts – Shelled Spanish	250	6-19	65-95
	253	Peanuts – Shelled Valencia (TC)	250	6-22	50-100
	290	Peanuts (shelled & roasted)	250	1-6	60-100
	202	Peanuts – Shelled Virginia	250	6-19	65-95
	678	Peanuts-Screened Splits	250	2-10	60-95



**AUXILIARY MODULE CALIBRATIONS AVAILABLE FOR STEINLITE SB900  
LISTED ALPHABETICALLY WITHIN COMMODITY SECTIONS**

Main Commodity	ID Number	Product	Testing Wt. In Grams	Moisture Range in Percent	Temperature Limits in Degrees F
	679	Peanuts-Whole Blanch Med Runner	250	2-10	60-95
	680	Peanuts-Whole Blanch Jumbos	250	2-10	60-95
	681	Peanuts-Hi-Cnt Blanch Splits(Doster)	250	2-10	60-95
	682	Peanuts-Med Blanch Virginia	250	2-10	60-95
	683	Peanuts-Rst Blanch Virginia Splits	250	2-10	60-95
	684	Peanuts-Xtra Large Blanch Virginia	250	2-10	60-95
	685	Peanuts-Resorts Blanch Virginia	250	2-10	60-95
	212	Peanuts (ground hulls)	125	4-15	60-100
	263	Peanuts (14/40 Granulated Hulls)(TC)	200	3-12	50-100
	717	Peanuts Ground Peanut Hull Pellets	250	7-17	60-95
	526	Peanut Meal	250	8-15.5	60-95
	278	Pecans #2 (shelled)	150*	2-15	50-90
	279	Pecans (shelled pieces)	150*	2-12	50-90
	280	Pecans (shelled Lrg Pieces & Halves)	150*	2-12	50-90
	390	Pecans (unshelled) Size 10 and up	200*#	3-16	60-95
	458	Pecans (unshelled) Below size 10	175*#	2-17	60-95
	524	Pecans (unshelled) Elliots	175*#	3-28	60-95
	429	Pecans (shelled) Bradley Halves (TC)	150*	1-14	60-110
	530	Pecans (shelled) Desirable Halves (TC)	170*	2-14.5	60-120
	525	Pecans (shelled) Elliot Halves (TC)	150*	2-17	60-120
	409	Pecans (shelled) Jumbo Halves (TC)	150*	2-12	60-110
	676	Pecans (shelled) Lg Hlvs Young Pcn	150*	2-10	60-95
	388	Pecans (shelled) Mammoth Halves (TC)	150*	2-12	60-110
	668	Pecans (shelled) Mammoth Hlvs Wichita	150*	2-12	60-95
	674	Pecan Jr (shelled) Mammoth Hlvs (TC)	150*	3-11	60-110
	532	Pecans (shelled) Native Halves (TC)	175*	1-18	60-120
	430	Pecans (shelled) West Schley Hlvs (TC)	150*	1-14	60-110
	666	Pecans Western Schley w/shell	200*	2-16	60-95
<b>NUTS CONT'D</b>	405	Pecans (shelled) Large Pieces (TC)	150*	2-10	60-110
	389	Pecans (shelled) Medium Pieces (TC)	150*	2-12	60-110
	423	Pecans (shelled) Small Pieces (TC)	150	1-14	60-110
	424	Pecans (shelled) Midget Pieces (TC)	150	1-14	60-110
	241	Pistachios #2 (unshelled) Raw	225	3-16	60-90
	557	Pistachios (Sinkers-Raw) (TC)	175	2-20	34-150
	558	Pistachios (Floaters-Raw) (TC)	175	2-20	34-150
	281	Pistachios (unshelled Rstd & Salted)	225	2-5	60-90
	556	Pistachios (unshelled Rst & Slt) (TC)	225	1-8	34-150
	282	Pistachios (shelled)	225	3-11	60-90
	555	Pistachios (Rst & Slt Meats) (TC)	200	1-8	34-150
	690	Pistachio Meats Roasted & slt w/shell	200	1-8	50-100
	691	Pistachio Whole Rst & slt w/shell	225	1-9	50-100
	692	Pistachio Whole Sinkers Raw	175	2-20	50-100
	693	Pistachio Floaters Closed Shell	175	2-20	50-100
	276	Walnuts (shelled halves) English	150	3-10	50-90
	277	Walnuts (shelled pieces) English	250	2-10	50-90
	521	Walnut (pieces Lrg Shell & Meats) (TC)	150	5-24	60-115

**AUXILIARY MODULE CALIBRATIONS AVAILABLE FOR STEINLITE SB900  
LISTED ALPHABETICALLY WITHIN COMMODITY SECTIONS**

Main Commodity	ID Number	Product	Testing Wt. In Grams	Moisture Range in Percent	Temperature Limits in Degrees F
	522	Walnut (pieces Sm. Shell & Meats(TC)	200	5.1-25	60-115
	629	Walnuts Dry Roasted Diced (TC)	210	1-5	40-110
	725	Walnut Shelled Pieces 3.5-6.5 mm	150*	2-10	60-95
	726	Walnut Shelled Pieces 6.5-9.5 mm	150*	2-10	60-95
	727	Walnut Shelled Pieces 9.5-13.0 mm	125*	2-10	60-95
	728	Walnut Shells & Meats 9.5-13.0 mm	125*	7-30	60-95
<b>OATS</b>	217	Grain Roasted Flaked Oats (TC)	120	4-15	70-120
	631	Ground Steam Rolled Oats (TC)	130	10-16	40-120
	317	Oat Groats	250	9-19	50-95
	707	Oats (oat meal)	175	8-16	60-95
	632	Steam Crimped Oats (TC)	130	8-18	40-120
	372	Steam Rolled Oats	130	10-16	60-90
<b>PEANUTS</b>	<b>(SEE NUT LISTING)</b>				
<b>PEAS</b>	403	Alaska Field Peas	250	8-18	65-90
	375	Canadian Field Peas (Century)	250	13-19	60-95
	292	Canadian Field Peas (Trapper)	250	11-21	60-95
	265	Cowpeas	250	10.5-21	60-95
	360	Cowpeas (Blackeyed)	250	8-17	60-95
	404	Green Peas (Whole)	250	9-18	60-95
	433	Green Peas (Split)	250	5-30	60-95
	434	Yellow Peas (Split)	250	5-30	60-95
	714	Pea Meal (flour)	200*	6-14	60-95
<b>PHARMACEUTICALS</b>	481	Gelatin Capsules (Filled)	203	2-3	60-95
<b>POPCORN</b>	272	Popcorn (CAP)	250	11-19	60-90
	225	Popcorn (P410)	250	12.5-17.5	70-85
	533	Popcorn (P608) Yellow (TC)	250	8-30	35-115
<b>POPCORN</b>	534	Popcorn (P615) Yellow (TC)	250	8-30	35-115
<b>CON'T</b>	535	Popcorn (P618) Yellow (TC)	250	8-30	35-115
	550	Popcorn (65K) Yellow	250	8-30	60-95
	551	Popcorn (70K) Yellow	250	8-30	60-95
	552	Popcorn (75K) Yellow	250	8-30	60-95
	553	Popcorn (80K) Yellow	250	8-30	60-95
	554	Popcorn (85K) Yellow	250	8-30	60-95
	228	Popcorn #3 Yellow/White	250	12-18	60-90
	536	Popcorn White Dynamite (TC)	250	8-30	35-115
<b>PSYLLIUM</b>	392	Psyllium #2 (Unextruded)	140**	6-15	50-90
		Psyllium (Pellets)	125	8-14	60-120
		Psyllium #2 (Granulated)	200	7-13	60-120

**AUXILIARY MODULE CALIBRATIONS AVAILABLE FOR STEINLITE SB900  
LISTED ALPHABETICALLY WITHIN COMMODITY SECTIONS**

Main Commodity	ID Number	Product	Testing Wt. In Grams	Moisture Range in Percent	Temperature Limits in Degrees F
<b>RAPESEED (SEE CANOLA LISTING)</b>					
<b>RICE</b>	351	Long Grain Rough Rice #4	250 ##	9-18	50-90
	560	Long Grain Rough Rice #5 (TC)	250 ##	4.5-29	35-120
	379	Hi-Temp Long Grain Rough Rice	250 ##	11.8-16	100-120
	350	Hulled Short Grain Brown Rice	250 ##	8-18	60-95
	435	Medium Grain White Rice	250 ##	6-18	60-95
	516	Med/Short Grain Cross White Rice	250 ##	8.5-18	60-115
	204	Long Grain White Milled Rice	250 ##	9-18	60-95
	223	Long Grain White Milled Rice #2	250 ##	12-15	60-95
	436	Long Grain White Rice 50% Broken	250 ##	6-18	60-95
	205	Long Grain Brown Rice	250 ##	9-18	60-95
	206	Long Grain White Milled Parboiled	250 ##	9-18	60-95
	207	Long Grain Brown Parboiled Rice	250 ##	9-18	60-95
	386	Processed White Milled Rice (TC)	125 ##	6-15	60-110
	387	Processed White Milled Parboiled (TC)	125 ##	6-15	60-110
	175	Brewers Rice	275 ##	6-16	60-95
	578	Rice Fractions	175	8.5-14.5	60-90
	315	Rice Millfeed	150	8-20	50-90
<b>SAFFLOWER</b>					
	539	Safflower Meal	250	7-15	60-90
<b>SESAME</b>					
	192	Sesame Seed	250	3-10.5	70-90
<b>SILICA</b>					
	308	Silica Gel (TC)	250	5-9	70-150
	538	Silica Gel #2 High Moisture (TC)	250	8-22	65-150
<b>SORGHUM</b>					
	595	Sorghum Almun	250	8-30	35-115
<b>SOYBEANS</b>					
	625	Solnuts (MT Replacer)	113	5-13	35-120
	146	Soybeans	250	9-18	50-90
	239	Soybeans 85 (TC)	250	9-18	35-100
	188	Soybeans #4	250	5-18	45-95
	179	High Moisture Soybeans (Italy)	250	18.1-30	65-95
	601	Lo-Temperature,Lo-Moist. Soybeans	250	7-12	32-65
	221	High Temperature Corrected Soybean	250	9-18	70-130
	349	Cracked Soybeans	250	8-18	65-85
	531	Cracked Soybeans #2 (TC)	250	4-22	60-120
	528	Soybeans Dried Plain Halves	200	1-6	60-95
	529	Soybeans Toasted Splits	250	2-12	60-95
	599	Steam Flaked Soybeans	250	10-17	60-90
	215	Grain Roasted Flaked Soybeans (TC)	190	4-15	70-120

**AUXILIARY MODULE CALIBRATIONS AVAILABLE FOR STEINLITE SB900  
LISTED ALPHABETICALLY WITHIN COMMODITY SECTIONS**

Main Commodity	ID Number	Product	Testing Wt. In Grams	Moisture Range in Percent	Temperature Limits in Degrees F
	603	Hi-Temp Lo-Moist. Roasted Soybeans	250	6-10	70-120
	604	Hi-Temp Lo-Mo Crimped Roasted Soy	225	6-10	80-120
	312	Soy Flour	250	8-20	50-95
	573	Toasted Soy Grits	225	6.7-11	60-90
	602	Ground Soy Hulls	150	10-15	80-100
	314	Ground Soy Hulls #2	150	10-15	80-100
	144	Soybean Meal	250	9-13	70-90
	145	Soybean Meal #2	250	9-13	70-90
	359	Soybean Meal #4 (TC)	250	9-16	70-130
	191	Soybean Meal Pellets	250	10-15	70-90
	167	Soybean Meal #3 (Ground Pellets)	250	10-18	65-90
	334	Soybean Mill Feed	200	8-14	60-90
	353	Soybean Mill Feed #2 (TC)	150	8-15	60-110
<b>SPELT</b>	380	Unhulled Spelt	150	8-20	60-95
	376	Hulled Spelt	250	9-18	50-95
<b>SUNFLOWER</b>					
	189	Sunflower #2 (Edible)	150	5-25	60-90
	549	Sunflower #4 (Edible) (TC)	110	4-27	34-150
	610	Sunflower #6 (Edible) (TC)	110	4-28	35-120
	194	Sunflower #2 (Oil)	150	5-25	65-90
	402	Sunflower #3 (Oil) (TC)	150	5-10	35-110
	229	Sunflower (Low Oil)	150	5-10	50-90
	298	Sunflower Meats	250	7-16	60-90
	244	Sunflower Oil Meal #2	200	8.5-15	60-95
<b>VEGETABLES</b>					
	344	Amaranth	200	6-18	60-95
	641	Asparagus (UC157)	250	4-16	60-95
	660	Artichoke	250	4-12	60-95
	168	Garden Beans	250	8-19	60-90
	336	Hyacinth Beans	250	8-20	60-95
	335	Yard Long Beans	250	8-20	60-95
	644	Basil Seed (Large Leaf)	225	4-16	60-95
<b>VEG'T</b>	321	Beet (Decorticated)	150	5-16	60-95
<b>CON'T</b>	650	Beet Seed (Detroit-Corticated)	150	4-16	60-95
	339	Spinach Beet	150	6-18	60-95
	324	Broccoli	200	5-15	60-95
	406	Cabbage	150	5-15	60-95
	544	Cabbage (Chinese)	150	4-21	60-95
	235	Cantaloupe Melon	150	6-15	60-95
	322	Carrot	150	5-15	60-95
	724	Carrot PPL med-coated	200	3-11	60-95
	326	Cauliflower	200	5-16	60-95
	407	Celery	200	5-15	60-95

**AUXILIARY MODULE CALIBRATIONS AVAILABLE FOR STEINLITE SB900  
LISTED ALPHABETICALLY WITHIN COMMODITY SECTIONS**

Main Commodity	ID Number	Product	Testing Wt. In Grams	Moisture Range in Percent	Temperature Limits in Degrees F
	545	Choisim	150	4-21	60-95
	659	Collards	250	4-12	60-95
	543	Coriander	150	4-21	60-95
	638	Coriander Seed Small	150	4-16	60-95
	646	Coriander Large	125	4-16	60-95
	327	Cucumber #1 (Beit Alpha MR)	200	6-15	60-95
	328	Cucumber #2 (Poinsett 76)	200	6-15	60-95
	673	Cucumber FMX(cross country)	200	4-14	60-95
	256	Eggplant (TC)	200	5-17	50-100
	643	Endives (Batavian)	200	4-16	60-95
	342	Gourd (Bitter)	150	6-18	60-95
	341	Gourd (Bottle)	125	6-18	60-95
	733	Gourd (Bottle) Large	200	5-16	60-95
	478	Gourd (Ridge)	200	4-21	60-95
	479	Gourd (Snake)	150	4-21	60-95
	343	Gourd (Sweet)	150	6-18	60-95
	542	Gourd (Wax)	150	4-21	60-95
	236	Honeydew Melon	200	6-15	60-95
	540	Kale (Chinese)	150	4-21	60-95
	480	Kang Kong (Sweet Potato)	250	4-20	60-95
	626	Leeks	250	6-18	35-120
	233	Lettuce	150	5-16	60-90
	718	Lettuce PPL Maxi –coated	200	1-9	60-95
	719	Lettuce Pro Flow-coated	200	1-9	60-95
	720	Lettuce PPH Maxi-coated	200	1-9	60-95
	723	Lettuce Oxykote-coated	300	1-9	60-95
	541	Mustard (Chinese)	150	4-21	60-95
	340	Okra	200	7-18	60-95
	323	Onion	150	5-15	60-95
	637	Onion – Polycoat	200	4-16	60-95
	721	Onion PPL maxi-coated	200	1-9	60-95
	640	Onion – Treated	200	4-16	60-95
	645	Onion – Fistulosum	200	4-16	60-95
	345	Papaya	100	7-18	60-95
	642	Parsley (Plain)	200	4-16	60-95
	169	Peas (Smooth Garden)	250	8-18	65-90
	170	Peas (Wrinkled Garden)	250	8-18	65-90
	219	Pepper (TC)	150	5-16	50-100
	337	Pepper (Chili) (TC)	150	5-16	50-100
	242	Pumpkin	150	5-16	60-95
	734	Pumpkin Large Seed	125	5-16	60-95
	669	Pumpkin Munchkin	185	4-16	60-95
VEG'T	325	Radish	150	5-16	60-95
CON'T	338	Spinach (Indian)	150	6-18	60-95
	699	Spinach (New Zealand)	100	6-17	60-95
	654	Spinach Seed (Alf Chrt'n)	210	4-40	60-95

**AUXILIARY MODULE CALIBRATIONS AVAILABLE FOR STEINLITE SB900  
LISTED ALPHABETICALLY WITHIN COMMODITY SECTIONS**

Main Commodity	ID Number	Product	Testing Wt. In Grams	Moisture Range in Percent	Temperature Limits in Degrees F
	671	Squash Pink Banana	150	4-14	60-95
	329	Squash #1 (Waltham Butternut)	200	6-15	60-95
	330	Squash #2 (Hybrid Genie)	200	6-15	60-95
	248	Sweet Corn (TC)	250	5-17	50-100
	420	Sweet Corn #2 (TC)	200	5-18	50-100
	421	Sweet Corn Shrunken Gene (TC)	200	5-17	50-100
	716	SweetCorn Hybrid Shrunken Type2	250	4-20	60-95
	232	Tomato	150	5-16	70-90
	220	Tomato (Defuzzed) (TC)	150	5-16	50-100
	722	Tomato PPL mini -coated	200	2-10	60-95
	639	Turnip Seed (Purple Top)	250	4-16	60-95
	234	Watermelon	175	6.5-16.5	60-90
	320	Watermelon #2	175	5-18	60-95
	230	Watermelon (Charleston)	175	6-15	60-95
	670	Watermelon (Honey Red)	175	4-14	60-95
	231	Watermelon (Sugar Baby)	175	6-15	60-95
	648	Zucchini Squash	200	4-16	60-95
	649	Zucchini Squash – Polycoat	200	4-16	60-95
<b>WHEAT</b>	515	Encora Rojo Wheat (TC)	250	6-14	60-115
	588	Daws #4 Bulgur	250	8-16	35-120
	590	Daws Half Cut Bulgur	250	8-16	35-120
	585	Daws #1 Bulgur	250	8-16	35-120
	594	Daws Raw Wheat	250	8-16	35-120
	587	Daws #3 Bulgur	250	8-16	35-120
	586	Daws #2 Bulgur	250	8-16	35-120
	593	Daws Whole Grain Non-Pearled Bulgur	250	8-16	35-120
	592	Daws Whole Grain Pearled Bulgur	250	8-16	35-120
	226	Hard Red Spring Wheat	250	9-18	50-90
	401	Hard Red Spring Wheat #4 (TC)	250	9-18	35-110
	173	Hard Red Winter Wheat	250	9-18	50-90
	238	Hard Red Winter Wheat #3 (TC)	250	9-18	35-100
	589	Madsen Raw Wheat	250	8-16	35-120
	591	S & E Organic Raw Wheat	250	8-16	35-120
	332	Soft Red Winter Wheat (TC)	250	9-18	35-110
	240	Soft Red Winter Wheat #2	250	9-18	50-90
	428	Kamut Wheat	250	8-19	60-95
	301	Triticale	250	9-20	65-95
	446	Flaked Wheat	225	13-30	60-90
	195	Flaked Wheat #2	210	15-30	60-90
	447	Unextruded Wheat Bran	200	10-20	50-90
	448	Extruded Wheat Bran	200	10-20	50-90
	449	Wheat Flour	250	8-17	75-85
	164	Flash Dried Wheat Gluten	250	5-10	75-85
	163	Gelatinized Wheat Starch	200	4-10	70-90
	162	Pearl Wheat Starch	225	5-13	70-90

**AUXILIARY MODULE CALIBRATIONS AVAILABLE FOR STEINLITE SB900  
LISTED ALPHABETICALLY WITHIN COMMODITY SECTIONS**

Main Commodity	ID Number	Product	Testing Wt. In Grams	Moisture Range in Percent	Temperature Limits in Degrees F
	715	Wheat Meal (flour)	200*	10-18	60-95
	243	Wheat Middlings	150**	10-17	60-90
	450	Wheat Middling Pellets	250	9-17	60-90
	303	Wheat Screenings	225	9-18	60-90
	574	Regular Bulgur	250	8-18	35-120
	576	Regular Bulgur Ca	250	8-18	35-120
	575	Soy Bulgur	250	8-18	35-120
	577	Soy Bulgur Ca	250	8-18	35-120
<b>WHEY</b>	247	Dried Whey	250	4-11	65-90
<b>WOOD</b>	408	Wood Pellets	250 ###	5-13	65-95
<b>YEAST</b>	268	Yeast #3 (O/G) (TC)	250	6-10	70-120
	267	Yeast #3 (S-60) (TC)	250	4-7	70-120

\*Requires Nut Funnel

\*\*Requires Compressor Block & Funnel

\*\*\*Nuts Greater Than 1.5 inches or 3.75 cm in length are excluded

#Nut Meat Conversion Chart Available

##For best results, pour initial weighed sample into grainbox before placing into funnel

###Wood pieces should not be greater than ¼ inch by ¼ inch by 1-1/2 inches long

TC – Specifically Temperature Corrected for that commodity

@ All nut calibrations are for raw product only unless otherwise stated on calibration title