

# MT-PRO+ PORTABLE GRAIN MOISTURE TESTER

# agraTronix™

1-800-821-9542  
www.AgraTronix.com

**NEW**



**Part No. 05100**  
**Carrying Case - Part No. 06053**  
**Replacement Cap - Part No. 06061**



**Convenient  
Clamshell  
Packaging**



**Carrying Case  
With Strap  
Included**

## FEATURES

- Direct readout for 40 different grain scales
- High frequency capacitive circuit with accurate temperature compensation circuit
- Illuminated, multilingual display - English, French, German, Italian, Portuguese, Spanish and Swedish
- Protective carrying case with shoulder strap included

## THE MT-PRO+ ADVANTAGE

- Automatically averages selectable number of tests
- Stores average calibration for all grains tested
- Direct readout for above limit and below limit values
- USB port for personalization (adding user name), grain scale, firmware and diagnostic updates
- Fewer push-buttons with standard interface configuration (up, down, left, right, enter)
- 2.5 in. LCD with selectable large or standard fonts, displays active function and allows user to scroll up/down through the numbered grain scales
- **Industry first** - Backlit push-button interface for low light conditions
- **Battery power indicator** - warning at power up when battery is below 15% capacity
- **Battery saver** - user selectable shut-down time

## SPECIFICATIONS

<b>Moisture Range</b>	<b>5% - 40% depending on grain tested</b>
<b>Temperature Range</b>	<b>32° - 113° F (0° - 45° C)</b>
<b>Repeatability &amp; Accuracy</b>	<b>±0.5% in normal moisture range for stored grain</b>
<b>Display Resolution</b>	<b>0.1% moisture</b>
<b>Battery</b>	<b>Two 9V batteries required</b>

agraTronix™

Leading Manufacturer of Electric Fencing Systems and Electronic Moisture Sensing Instrumentation.  
10375 State Route 43 | Streetsboro, Ohio 44241 | © 2011 AgraTronix, LLC. All Rights Reserved.